



FOR CONCRETE ROADWAY:  
 DRILL AND DOWEL INTO EXISTING CONCRETE.  
 POUR CONCRETE CAP TO MATCH EXISTING  
 CONCRETE. USE A HI-EARLY CONCRETE MIX  
 WITH # 3 REBAR ON 12 INCH CENTERS BOTH  
 WAYS.

# CONCRETE PAVEMENT REPAIR DETAIL



PREPARED BY  
THE CITY OF SULPHUR SPRINGS  
ENGINEERING DEPARTMENT

CITY OF SULPHUR SPRINGS  
DEVELOPMENT MANAGEMENT MANUAL  
DETAIL DRAWINGS

CONCRETE PAVEMENT  
REPAIR  
DETAIL

SCALE: NTS  
 DATE: 4.09.2015  
 DR. BY:  
 CK. BY:

DRAWING NUMBER  
**FIG.-3.04**